



## **Tempasure™**

**Quality Assurance for Low Temperature Sensitive Products**

**Descending Temperature points**

### **Instructions for Use**

Allow sensor to stabilise at product temperature

Pull safety tab to activate sensor

Remove release liner and attach with self adhesive backing

A clear window indicates that the unit has not been exposed to critical low temperatures

Indicator window shows red when exposed to low temperature that is at or below its rating.

24/10/2008

Riverside Buildings, Dock Road, Connah's Quay, Flintshire, CH5 4DS