



## Chillchecker<sup>®</sup>

---

### Instructions for Use

---

**Product Description:** Temperature Assurance Indicator

---

**Standard Range:** -17 to +20°C

**Directions:** Peel release paper from the back of the indicator and apply to the subject being measured.

Cool below specified rating prior to activating

To activate, push the centre of the indicator (by hand)

**Indication:** Staining of the white paper will be seen should the temperature rating be exceeded

**Storage:** It is recommended that the indicators be stored in a refrigerator prior to use

24/10/2008

Riverside Buildings, Dock Road, Connah's Quay, Flintshire, CH5 4DS